

Hand Swaged DIY Kit - Jaw/Jaw Rigging Screw & Saddles



Hand Swaged DIY Kit for Balustrading using Saddles

Kit Includes

- 2 x Saddles
 - 4 x Stainless Screws or Pop Rivets
 - 1 x Jaw/Jaw Rigging Screw
 - 2 x 3mm Thimble
 - 2 x 3mm Ferrule (swage)
- Use 7x7 3.2mm wire with this kit

Rating: Not Rated Yet

Price

\$ 9.80

\$ 0.89

[Ask a question about this product](#)

Description

These kits are perfect for anyone who is building a balustrade that is using timber or steel posts. They are easy to install and require little to no prior experience.

Kit Includes

- 2 x Saddles
- 4 x Stainless Screws
- 1 x Jaw/Jaw Rigging Screw
- 2 x 3mm Thimble
- 2 x 3mm Ferrule (swage)

At one end you will use:

1 x Saddle
2 x Screws
1 x Thimble and Ferrule

At the other end:

1 x Saddle
2 x Screws
1 x Thimble and Ferrule
1 x Jaw/Jaw Rigging Screw (to tension the wire)

If you are not sure how many wires/kits you require see our [Balustrade Regulations](#) page for more information.

// //